



## INSTALLATION INSTRUCTIONS

**PART No.** 30495

**MODEL No.**

**Hood Vent**

Remove the screw from the cowl vent.

With rubbing alcohol clean the entire top of the cowl vent area.

**NOTE:** If surface is **NOT** cleaned, the 3M tape will not stick thus voiding any warranty.

Peel off the outer tape covering from the 3M tape. With help, place the stainless steel hood vent in place on the cowl. Make sure alignment is correct before securing to cowl.

Use a rag to apply pressure to the top surface of the hood vent to ensure correct bonding of tape.



## INSTALLATION INSTRUCTIONS

**PART No.** 30495

**MODEL No.**

**Hood Vent**

Remove the screw from the cowl vent.

With rubbing alcohol clean the entire top of the cowl vent area.

**NOTE:** If surface is **NOT** cleaned, the 3M tape will not stick thus voiding any warranty.

Peel off the outer tape covering from the 3M tape. With help, place the stainless steel hood vent in place on the cowl. Make sure alignment is correct before securing to cowl.

Use a rag to apply pressure to the top surface of the hood vent to ensure correct bonding of tape.